

B-Series MIG Guns

Semi-Automatic, Air-Cooled, MIG Welding Gun






Siemensstr. 89 · D-47574 GOCH · GERMANY

Tel.: +49 (0)2823 8 79 96-0 · Fax: +49 (0)2823 8 79 96-29 e-mail: info@ewsgmbh.com · www.ewsgmbh.com

PARTS LIST - B-Series Replacement Parts for 200, 300, 400 & 500 Amps




ITEM #	PART #			DESCRIPTION	
	Q20	Q30	Q40	Q50	
	152-1	152-10-62C 152-30-62C			Nozzle, CMI Taper-LOCK™
1	R401-5-62		R401-6-62		Nozzle, Tregaskiss™ Comparable
	B4391		B4491	B4591	Nozzle, Bernard™ Comparable
	See Nozzle Selection				Nozzle, Optional Available
2	See Contact Tip Selection				Contact Tip
		154-	Diffuser, CMI Taper-LOCK™		
		R40	Diffuser, Tough Lock™ Comparable		
3	B4335		B4435		Diffuser, Short Eliptical Tip
	B4235		B4635		Diffuser, Long Eliptical Tip
4	B10012				Neck Insulator, CMI Taper-LOCK™/Tough Lock™
4	B43	23R	B44	23R	Neck Insulator, Eliptical
5	Se	e <i>Neck</i> in <i>Orde</i>	ering Informat	ion	Neck
6	B4213B	B43	13B	B4513B	End Fitting
7	B4:	305	B1540003	B4416	Cone Nut
8	B1880155		N	/A	Handle Kit, Small
	N	/A	B1880198	N/A	Handle Kit, Medium
		N/A		B4408	Handle Kit, Large
9		B5662		B4422	Trigger Assembly
10	B2520074		N	/A	Spring for Small Handle
	N	/A	B2520042	N/A	Spring for Medium Handle
	N/A			185-40-001	Spring for Large Handle
11	B4209			B4409	Handle Screw
12		B4207		B4407	Post Fastener
	B1880004		B4426	Screw/Post Kit	
13		B252	10066		Strain Relief Kit
14		B2520041S		B2520041	Strain Relief Spring
15		B1010	0027R		Adapter Block
16	214				Power Pin, Tweco® #4
17	214-1 214-116 214-332				Power Pin, Miller® Power Pin Cap, .023"-1/16" Power Pin Cap, 5/64"-3/32"
18	214-25			Power Pin, Lincoln® PM & LF	
19	214-7				Power Pin, Lincoln® LN
20	B5060CM				Euro Connector Plug
21	B4816				Euro Connector Nut
22	BGN2021				Control Plug, Miller® / Lincoln® PM
23	B4719				Control Plug, Lincoln® LN & LF
24	See Liner Selection				Liner


Consumable Selection

Nozzles (Optional Available)


CM Industries Taper-LOCK™



Comparable to Tregaskiss™





Comparable to Bernard™




Contact Tips

CM Industries Taper-LOCK™ Contact Tips






Comparable to Bernard™ Eliptical Contact Tips



Comparable to Tregaskiss™ Tough Lock™ Contact Tips



Heavy Duty R403-20-30 0.030" (0.8mm) R403-20-35 0.035" (0.9mm) 0.040" (1.0mm) R403-20-1.0 0.045" (1.2mm) R403-20-45 R403-20-364 3/64" (1.2mm) 0.052" (1.4mm) R403-20-52 1/16" (1.6mm) R403-20-116 0.071" (1.8mm) R403-20-1.8 5/64" (2.0mm) R403-20-564 R403-20-332 3/32" (2.4mm)



Heavy Duty - Tapered R403-21-30 0.030" (0.8mm) 0.035" (0.9mm) R403-21-35 R403-21-1.0 0.040" (1.0mm) 0.045" (1.2mm) R403-21-45 0.052" (1.4mm) R403-21-52 R403-21-116 1/16" (1.6mm)



Extra Heavy Duty R603-20-45 0.045" (1.2mm) 0.052" (1.4mm) R603-20-52 R603-20-116 1/16" (1.6mm) 5/64" R603-20-564 (2.0 mm)R603-20-332 3/32" (2.4mm)

Liners

Universal Conventional Liners

10' (3.05m) Gun Lengths		15' (4.57m) Gun Lengths	
L3A-10	for 0.035" - 0.045" wire	L1A-15	for 0.023" - 0
L4A-10	for 0.045" - 1/16" wire	L2A-15	for 0.030" - 0
		L3A-15	for 0.035" - 0
		L4A-15	for 0.045" -
		L6A-15	for 5/64" wir
		L7A-15	for 3/32" wir

L1A-15	for 0.023" - 0.030" wire
L2A-15	for 0.030" - 0.035" wire
L3A-15	for 0.035" - 0.045" wire
L4A-15	for 0.045" - 1/16" wire
L6A-15	for 5/64" wire
L7A-15	for 3/32" wire
L8A-15	for 7/64" - 1/8" wire

25' (7.62m) Gun Lengths					
L1A-25	for 0.023" - 0.030" wire				
L2A-25	for 0.030" - 0.035" wire				
L3A-25	for 0.035" - 0.045" wire				
L4A-25	for 0.045" - 1/16" wire				
L6A-25	for 5/64" wire				
L7A-25	for 3/32" wire				

Conventional Liners for Aluminum

10' (3.05m) Gun Lengths 415-45-02 for 0.035" - 3/64" wire Polymer Liner 415-116-22

for 3/64" - 1/16" wire Polymer Liner

15' (4.57m) Gun Lengths 415-45-03 for 0.035" - 3/64" wire Polymer Liner 415-35-22 for 0.035" - 0.045" wire Steel Wrapped Nylon for 0.045" - 1/16" wire 415-116-2 Steel Wrapped Nylon for 0.045" - 1/16" wire 415-116-23

Polymer Liner

25' (7.62m) Gun Lengths

L8A-25

415-45-04 for 0.035" - 3/64" wire Polymer Liner

for 7/64" - 1/8" wire

Ordering Information

Amperage 200 Amps **BQ20**

BQ30 300 Amps **BQ40** 400 Amps **BQ50** 500 Amps

Gun Length

25

08 8 ft. (2.44m) 10 10 ft. (3.05m) 12 12 ft. (3.66m) 15 15 ft. (4.57m) 20 20 ft. (6.16m)

25 ft. (7.63m)

Handle and Trigger

200, 300 Amp Standard Trigger Small Handle

400 Amp Standard Trigger

Medium Handle

500 Amp Standard Trigger

Large Handle

BQ40 15 A E 4E M

Neck Rotatable, Short 30° BQT2-30 В Rotatable, Short 45° BQT2-45 60° C Rotatable, Short BOT2-60 Rotatable, Short 80° BQT2-80 D 30° BQT3-30 Rotatable, Medium Е Rotatable, Medium 45° BQT3-45 Rotatable, Medium 60° BQT3-60 K Rotatable, Medium 80° BQT3-80 G Rotatable, Long 30° BQT5-30 45° ROT5-45 Rotatable, Long н Rotatable, Long 60° BQT5-60 N Fixed, Short 30° BOT2-30 0 Fixed, Short 45° BQT2-45 Fixed, Short 60° BQT2-60 w Fixed, Short 80° BOT2-80 Q Fixed, Medium 30° BQT3-30 45° ROT3-45 R Fixed, Medium S Fixed, Medium 60° BQT3-60 Х 80° BQT3-80 Fixed, Medium Т Fixed, Long 30° BQT5-30 U Fixed, Long 45° BQT5-45

Contact Tip CMI Taper-LOCK™

0.030" (0.8mm) 0.035" (0.9mm) 4B 155-1-030 4C 155-1-035 0.040" (1.0mm) 4D 155-1-040 0.045" (1.2mm) 4E 155-1-045 4F 3/64" (1.3mm)155-1-364 0.052" (1.4mm) 155-1-052 4H 41 1/16" (1.6mm) 155-1-062 4K 5/64" (2.0mm)155-1-564 3/32" (2.4mm) 4L 155-1-332

Comparable to Tregaskiss™

3B	0.030" (0.8mm)	R403-20-30
3C	0.035" (0.9mm)	R403-20-35
3D	0.040" (1.0mm)	R403-20-1.0
3E	0.045" (1.2mm)	R403-20-45
3R	3/64" (1.3mm)	R403-20-364
3H	0.052" (1.4mm)	R403-20-52
31	1/16" (1.6mm)	R403-20-116
3K	5/64" (2.0mm)	R403-20-564
3L	3/32" (2.4mm)	R403-20-332

Power Pin

Bernard™ Ε Euro н Hobart®

Lincoln® LN

S Lincoln® LF/Power Feed Lincoln® Power MIG R

Miller® M 0 OXO®

P Panasonic®

Т Tweco® 4 (Standard Lead)

Tweco® 5 (Standard Lead) W Tweco® 5 (Miller Lead)

*Universal Conventional Liner

CM Industries, Inc. is in no way affiliated with above-named manufacturers. References to above-named parts, feeders, and part numbers are for your reference only.

SAFETY WARNINGS! READ BEFORE USE



The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the welding power source Owner's Manual.

60° BQT5-60



Fixed, Long

Read and follow all Safety Standards.

Only qualified persons should install, operate, maintain, and repair this equipment. A qualified person is defined as one who, by possession of a recognized degree, certificate, or professional standing, or who by extensive knowledge, training and experience, has successfully demonstrated ability to solve or resolve problems relating to the subject matter, the work, or the project and has received safety training to recognize and avoid the hazards involved.



During operation, keep everybody, especially children, away



ELECTRIC SHOCK can kill.

- Always wear dry insulating gloves.
- Insulate yourself from work and ground.
- Do not touch live electrode or electrical parts. Replace worn, damaged, or cracked guns or cables.
- Turn off welding power source before changing contact tip or gun parts.
- Keep all covers and handle securely in place.



FUMES AND GASES can be hazardous.

- Keep your head out of the fumes.

 Ventilate area, or use breathing device. The recommended way to determine adequate ventilation is to sample for the composition and quantity of fumes and gases to which personnel are exposed.
- Read and understand the Safety Data Sheets (SDSs) and the manufacturer's instructions for adhesives, coatings, cleaners, consumables, coolants, degreasers,



WELDING can cause fire or explosion.

for adhesives, coatings, cleaners, consumables, coolants, degreasers, fluxes, and metals



MOVING PARTS can injure.

- Keep away from moving parts.
- Keep away from pinch points such as drive rolls.



ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.

• Wear an approved welding helmet fitted with a proper shade of filter

- lenses to protect your face and eyes from arc rays and sparks when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- · Use protective screens or barriers to protect others from flash, glare and sparks; warn others not to watch the arc.
- Wear body protection made from durable, flame-resistant material (leather, heavy cotton, wool). Body protection includes oil-free clothing such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.



- BUILDUP OF GAS can injure or kill.

 Shut off compressed gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



Noise from some processes or equipment can damage hearing.

- Check for noise level limits exceeding those specified by OSHA.
- Use approved ear plugs or ear muffs if noise level is high. · Warn others nearby about noise hazard.



WELDING WIRE can injure.

Keep hands and body away from gun tip when trigger is pressed.



READ INSTRUCTIONS.

Read and follow all labels and the Owner's Manual carefully before installing, operating, or servicing unit.



- Use only genuine replacement parts from the manufacturer
- . Perform installation, maintenance, and service according to the Owner's Manuals, industry standards, and national, state, and local codes



- HOT PARTS can burn.Allow gun to cool before touching.
- Do not touch hot metal.
- Protect hot metal from contact by others.

CALIFORNIA PROPOSITION 65 WARNING
This product contains chemicals, including lead, known to the State of California to cause cancer, birth defects, or other reproductive harm. Wash hands after use. (California Health & Safety Code Section 25249.5)